

# TECHNICAL DATA SHEET

## 1. IDENTIFICATION OF THE PRODUCT

---

**NAME OF THE PRODUCT** P2000 Grey carbon block for first roughing  
**CODE** 100819

## 2. DESCRIPTION

---



Designed to remove imperfections and defects of paint and varnish applications, like take offs or spots produced during the application.

We offer different grains to use depending of the size of imperfections.

## 3. APPLICATION

---

### A.1st step

First use: keep carbon blocks submerged in water for 24 hours, because these carbon blocks are designed to work in wet conditions. If carbon blocks are not used in this wet conditions, they can scratch the treated surface.

### B. 2nd step

Wet sanding.

### C.3rd step

Once you finish work, just keep carbon blocks inside a closed container, without water, to keep them moist, but no wet.

Otherwise, carbon blocks can suffer deterioration and in other uses can produce scratches. Use the straightening block (ref. 100823) to ensure that carbon blocks are in perfect conditions.

The technical information is in accordance with our experience. We assure the quality of the product. However, the conditions of use are not under our control and we cannot assume any responsibility of the obtained results.