


TECHNICAL DATA SHEET

1. IDENTIFICATION OF THE PRODUCT AND THE COMPANY

NAME OF THE PRODUCT	High gloss dressing gun EVERGREEN
CODE	100883
DISTRIBUTOR	BOSSAUTO INNOVA, S.A.
ADDRESS	c/ Thomas Edison 16, Apartado de correos 95
CITY	08430 La Roca del Vallés (Barcelona) SPAIN
PHONE	+ 34 93 860 49 23
FAX	+34 93 871 23 36
E-MAIL	info@bossauto.com
WEB	www.bossauto.com

2. DESCRIPTION


Cleans carpets, plastics, and upholstery interior. Blast cleaning solution into crevices unable to reach by hand. Low moisture, atomizes cleaner and detergent into 1~10µm. Please use the micro-particle cleaning gun in the safe, and secure environment. Read the direction for use carefully, before you use the cleaning gun



Dimensions (mm)	W110, D230, H235
Weight (Kg)	0,5
Air pressure (Psi)	75 – 115
Air consumption (L/min)	190
Container (ml)	250
Detergent	Neutro
Volume spray max. (ml/min)	18
Working temperature (°C)	10-50
Air intake	1/4"

A. Method of liquid adjusting valve/fixed valve:

Fixed Valve screw allows to adjust the air flow. Once the Air pressure is fixed, please tighten up the fixed valve.



B. Advertencia


The pressure must be set between 0.5 to 0.8MPa; higher pressure (>0.8MPa) may cause damage to the equipment and dangerous event. Use ONLY neutral liquid. Specially note that organic solvent even in neutral feature cannot be used, because it contains enormous factors might cause deterioration.

3. MAINTENANCE METHODS/TIPS


Cleaning after use. Use water or other specialized chemical solution to clean the spray tube, cone, and bottle. Preserve it at ventilated and dry place without direct sun irradiation.

If the device is not cleaned after use, dust and bacteria residue will seriously corrode the device and greatly reduce the use life of the device.


1. First: put clean water or specialized solutions into tank. Put the tube into tank, and release pressure by pulling the trigger on gun for 1-2 minutes.



2. Second: put the cone part into the tank, and release pressure by triggering the gun for 1 minute. (Note: Special acting requires for individual tools, please refer to the instruction for us for each tools)



3. Third: triggering the gun in the air for 1 to 2 minutes. Preserve it at ventilated and dry place without direct sun irradiation.



- Weighed tube, cone, and other accessories are consumables. The use life of the consumables may vary from the frequency of use, and user's habits.
- Never point the cleaning guns in the direction of human body, face, and eyes. Wear safety goggle and respirator during the operation.
- We shall not be responsible for device damage caused by application of unoriginal accessories and special consumables, or your own repair, parts replacement, and disassembly of the device. In such case, even the device is still under limited warranty, such repair shall not be provided for free.
- In case of any abnormality or damage of the equipment during the use process, please terminate the operation immediately.

The technical information is in accordance with our experience. We assure the quality of the product. However, the conditions of use are not under our control and we cannot assume any responsibility of the obtained results.