



INSTRUCTIONS FOR USE

- 1 Please, be sure to connect in a **110 volt/ 230 volt** power source.
- 2 Select the heating temperature according to thickness and plastic type.
 - Thickness of plastic fine until 1.5mm.
 - Thickness of plastic fine until 2 mm.
 - Thickness of plastic hard with more than 2 mm.
- 3 Choose the type of staple and positioned it in the electrode.



- 4 Apply the staple above the inner side of the area to be repaired.
- 5 Press the start button and press on the staple until be correctly inserted in the plastic material to repair.



- 6 Release the button and wait a few seconds until the staple is cool.
- 7 Repeat the operation to complete the repair work.
- 8 Cut the excess of the staples with the pliers included in the kit.

MANUAL

KIT UNIPLAST: Sewing kit in hot for plastic.
With the KIT UNIPLAST you can repair and reinforce all plastic parts of the car as bumpers, instrument panels, headlight supports, fairings, etc.

ATTENTION: Before using the KIT UNIPLAST read the manual.



INDEX

- | | |
|--|-----|
| 1. Technical Features. | p.1 |
| 2. Name of components and Kit items. | p.2 |
| 3. Special warnings and precautions for use. | p.3 |
| 4. Instructions for use. | p.4 |

TECHNICAL FEATURES

Type	Uniplast 220 V	Uniplast 120 V
Voltage	230V/50-60Hz	110V/50-60Hz
Absorbed power	40W	40W
Secondary Voltage	1.5V-1.7V-2.0V	1.5V-1.7V-2.0V
Secondary intensity	14.9A-16.8A-19.3A	14.9A-16.8A-19.3A
Weight	1.7Kg	1.7Kg
Dimensions	180 x 90 x 90 mm	180 x 90 x 90 mm

NAME OF COMPONENTS AND KIT ITEMS

- | | | |
|---|--|---|
| 1 | Briefcase | 1 |
| 2 | Welder KIT UNIPLAST | 1 |
| 3 | Steel staples FU 0.8 mm (50 pcs.) 090042 | 1 |
| 4 | Steel staples FS 0.8 mm (50 pcs.) 090044 | 1 |
| 5 | Steel staples FV 0.8 mm (50 pcs) 090045 | 1 |
| 6 | Power cable 220V 2mt | 1 |
| 7 | Instructions manual | 1 |



SPECIAL WARNINGS AND PRECAUTIONS FOR USE

For your security, please read this manual carefully.

The staple inserted in the electrodes during the soldering phase, the temperature can rise to over 500°C.

Pay close attention; an incorrect handling can cause serious burns and initiate a fire.

- Use appropriate heat resistant gloves during the working time.
- Before introduce the staple, be sure that the electrodes are cold.
- Do not touch the staple during the warm-up phase.
- Do not use in the presence of flammable fuel.
- Do not use with wet hands.
- Do not use in environment wet.
- Wait after use.
- This product has specially been developed for plastic repairing.
- The KIT UNIPLAST should be used only with the original consumable.
- Welding consumable FU0.6, FU0.8, FS0.6, FS0.8, FV0.8, FM0.7



DECLARACION DE CONFORMIDAD
DECLARATION OF CONFORMITY
DECLARATION DE CONFORMITE

DICHLARAZIONE DI CONFORMITA
DECLARAÇÃO DE CONFORMIDADE

Si dichiara che la macchina tipo:
We hereby state that the machine type:
On déclare que la machine type:
Se declara que el aparato tipo:
Declara-se que o tipo de aparelho:

UNIPLAST

é conforme alle direttive:
is in compliance with the directives:
est conforme aux directives:
es conforme a las directivas:
é conforme a las directivas:

EN 50063
EN 50199

e che sono state applicate le norme:
ant that the following standards apply:
et qu'on a appliqué les normes:
y que se han aplicado las normas:
eque foram aplicadas las normas:

DIR 2004/108/CE
DIR 2006/42/CE
DIR 2006/95/CE